

Partnumber	Description
76.0.116.1	98.6.001.724 Power Supply 125W PC-ATX incl.mnt.plate
76.0.802.1	98.6.001.711 Power supply 115-230Vac * replacement *
76.0.811	98.6.001.711 Parallel I/O-card D25F PCI-low
76.0.816.1	Hub 8-port 100Mb/s RJ45 24Vdc replacement
76.0.847.1	Switch 18-port 100Mb/s RJ45 24Vdc replacement
91.6.040.400	RS232 > RS232/422/485 converter for M-PC
91.6.040.401	TTL > RS232/422/485 converter for CP
91.6.040.402	TTL > RS232/422/485 converter for CP ** data inverted **
91.6.040.500	Masterclk interface REV A
91.6.040.501	Frequency Input Divider Rev.B
91.6.040.503	Navigation alarm unit
93.0.315	Cabin Unit Praxis 3-led Rev.HBA
93.0.350	WATCH ENTRANCE UNIT REV B
93.0.351	Alarm Reset Box bulkh.mnt.
93.0.352	Audible Alarm box
93.0.354	RESET+ BUZZER BOX REV B
93.0.355	W.ENTR.UNIT -KEYSW. REV A
93.0.356	RESET+ BUZZER BOX REV A
93.0.359	Watch entrance unit Maxiguard
93.0.362	Ethernet conn.box 2xUTP/RJ45 white
93.0.363	Bedroom buzzer/accept box LOP
93.0.369	Watch entrance unit *PG16 glands*
93.0.370	Alarm Reset Box *PG13 glands*
93.0.371	Watch entrance unit+ Timer On/Off
93.4.500	PSU din-module 60/120/240/480W
93.4.501	UPS distribution panel 8-way DIN-rail mnt.
93.6.021.007	Funct.key.fl.pan.mnt 18key track. USB
93.6.021.004	Pro-serie KEYBOARD Marine PC DINS and PS/2
93.6.021.005	Pro-serie QWERTY Keyboard Fl.pan.mnt. PS/2
93.6.021.204	Pro-serie TRACKBALL PS/2
95.1.001	ORDER PRINTER Isolated Supply
95.6.10P.701	Sensor Adaptor Thermocouple Input
95.6.10P.702	Sensor Adaptor 0-1V Input
95.6.10P.703	Sensor Adaptor 0-10V Input
95.6.10P.704	Sensor Adaptor PT100 -40/100 Degr.C Input
95.6.10P.705	Sensor Adaptor PT100 -40/750 Degr.C Input
95.6.10P.706	Sensor Adaptor Pot.inp. 0-5K/0-10K
95.6.10P.707	Sensor Adaptor Pot.inp. 0-1K/0-2K
95.6.10P.708	Sensor Adaptor 0/4-20mA Input Active Sensor
95.6.10P.709	Sensor Adaptor 0/4-20mA Input Passive Sensor
95.6.10P.710	Sensor Adaptor Freq.inp 0-2kHz
95.6.10P.711	Sensor Adaptor Freq.inp 0-4kHz
95.6.10P.712	Sensor Adaptor Digital Input
95.6.10P.713	Sensor Adaptor Digital Input Active 24VDC/AC

Partnumber	Description
95.6.10P.714	Sensor Adaptor Analog Output 0/4-20mA
95.6.10P.715	Sensor Adaptor Relay Output
95.6.10P.716	Sensor Adaptor Freq.inp 0-100Hz
95.6.10P.717	Sensor Adaptor Freq.inp 0-1kHz
95.6.10P.719	Sensor Adaptor 2-Wire PT1000 Input
95.6.10P.720	Sensor Adaptor Digital Input with 2 COM
95.6.10P.721	Sensor Adaptor Digital Output With 2 COM
95.6.10P.723	Sensor Adaptor Open Collector Output
95.6.10P.725	Sensor Adaptor Freq.inp 0-10kHz 20% duty
95.6.10P.727	Sensor Adaptor Fast AI 0-20mA (High Isolation)
95.6.10P.728	Sensor Adaptor Fast AI Potmeter 1K/2K/5K (High Isolation)
95.6.10P.730	Pro-serie Sensor Adaptor Dinrail backlight pcb
95.6.10P.731	Sensor Adaptor Fast AI 0-1V (High Isolation)
95.6.10P.732	Sensor Adaptor Input adapter for NTC
95.6.10P.733	Sensor Adaptor Fast AI PT100 -40/750 Degr.(High Isolation)
95.6.10P.734	Sensor Adaptor DI Active 24Vdc/ac (High Isolation)
95.6.10P.735	Sensor Adaptor Analog Output 0-1mA
95.6.10P.736	Sensor Adaptor Relay Output 24Vdc Only (Fused)
95.6.10P.737	Sensor Adaptor Relay Output with varistors
95.6.10P.738	Sensor Adaptor 0-5V input
95.6.10P.739	Sensor Adaptor -10V / +10V Input
95.6.10P.740	Sensor Adaptor DI Active 24Vdc/ac for DP (High Isolation)
95.6.10P.741	Sensor Adaptor Fast AI 0-1V for DP (High Isolation)
95.6.10P.742	Sensor Adaptor +5V/0V/-5V Output
95.9.001	Spare set fuses DIN
95.9.007	Spare set fuses ATO
98.0.313	Drive unit DD16 replacement kit 230Vac
98.0.314	Areg Actuator motor replacement kit 230Vac
98.6.001.701	6001-PC server 2x10Mb
98.6.001.711R	6001-PC server + LPT-card **Refurbished**
98.6.001.725.3	6001-MPC low prof.24Vdc SSD 2Gb + LPT
98.6.001.725.4	6001-MPC low prof.24Vdc SSD 16Gb + 2xUSB + LPT
98.6.001.728	Pro-serie 6001-MPC low prof.24Vdc SSD+HDD+2xUSB
98.6.010.700	6010-700 I/O-server DIN-rail+ 2m cable
98.6.010.701	Sensor supply/Earthfault mod.DIN-rail
98.6.010.7011	Sensor supply/Earthfault mod.DIN-rail (High Isolation)
98.6.010.706	Motion Controller ED110AC-440AC
98.6.020.613	PMS operator panel fl.pan.mnt.
98.6.020.614	PMS-H operator panel fl.p.mnt.
98.6.020.645	BMS Operator Panel Rev.EC
98.6.020.648	BMS Operator Panel Wing Rev.EC
98.6.020.651	MONx 12" LCD TFT PANEL
98.6.021.601	LOP-2 + horn/accept
98.6.021.602	LOP-3/ PMS+ horn/accept

Partnumber	Description
98.6.021.602R	LOP-3/PMS + horn/accept Russian
98.6.021.604	Governor operator panel flpmnt
98.6.021.605	PMS-O operator panel fl.p.mnt.
98.6.021.606	Maxiguard display module
98.6.021.607	LOP-1/2 Fire Alarm Panel
98.6.021.608	LOP-3 -Fire Alarm Panel
98.6.021.613	PMS operator panel fl.pan.mnt.
98.6.021.614	PMS-H operator panel fl.p.mnt.
98.6.021.6211	Speed setting lever+ telegraph (single)
98.6.021.6212	Speed setting lever+ telegraph (double)
98.6.021.6213	Speed setting lever+ telegraph (single)+ CAM-switches
98.6.021.6214	Speed setting lever+ telegraph (single) elec.shaft
98.6.021.6215	Speed setting lever+ telegraph (double)+ el.shaft
98.6.021.628	BMS telegr.panel incl.dimming
98.6.021.629	BMS telegr.panel excl.dimming
98.6.021.639	Telegraph ER-panel AS/AH
98.6.021.642	BMS TFT-operator panel
98.6.021.642B	BMS TFT-operator panel Black
98.6.021.649	Rate of Turn (ROT) Operator panel
98.6.021.649B	Pro-serie Rate of Turn (ROT) Operator panel Black
98.6.021.650	Joystick / Trackerball operator panel
98.6.021.653	MONx 12" LCD TFT PANEL TOUCH SCREEN
98.6.030.702	DIN I/O-module 12di/8do
98.6.030.7020	DIN I/O-module 12di/8do + dipswitches
98.6.030.7021	DIN I/O-module 12di/8do (high Isolation)
98.6.030.703	DIN I/O-module 12di/12do
98.6.032.702	DIN I/O-module 24di
98.6.032.7020	DIN I/O-module 24di + dipswitches
98.6.032.7021	DIN I/O-module 24di (High Isolation)
98.6.034.702	DIN I/O-module 16ai
98.6.034.7020	DIN I/O-module 16ai + dipswitches
98.6.034.7022	DIN I/O-module 16ai (High Isolation)
98.6.034.703	DIN I/O-module 16-mixed
98.6.034.7030	DIN I/O-module 16-mixed + dipswitches
98.6.034.704	DIN PMS I/O-module (old type)
98.6.034.7050	DIN I/O-module 16-mixed (High Isolation)
98.6.034.706	DIN PMS I/O-module
98.6.034.708	DIN Emergency I/O-module
98.6.034.7081	DIN Emergency I/O-module
98.6.034.709	DIN Indication I/O-module 3-pos
98.6.034.7091	DIN Indication I/O-module 4-pos
98.6.034.710	DIN I/O-module 16-mixed for DP
98.6.040.701	6040-701 DIN fiber/CAN conv.
98.6.049.706	DIN Control Processor module Rev. S1A

Partnumber	Description
98.6.049.7061	DIN Control Processor module+ Dimming
98.6.049.7062	DIN Control Processor module (RS485)
98.6.049.7063	6049-7063 Praxis Rev.CA
98.6.049.7064	6049-7064 Praxis Rev.AA
98.6.049.7065	6049-7065 Praxis Rev.K1A
99.8.017	Pro-serie Cable RS232 9P-Loose-ends (for M-PC) l=5m
99.8.020	Pro-serie Cable RS232 4p loose-ends (for CP) l=2m
99.8.021	Pro-serie Cable download Sub-D9p (for CP) l=5m
99.8.022	Pro-serie Cable RS485 4p loose-ends (for CP) l=2m
99.8.023	Pro-serie Mains socket 4v+cable-EUROmale
99.8.025	Pro-serie Cable 6049-706 <=> Telegraph panel l=2m
99.8.026	Pro-serie Cable 6049-706 <=> LOP/PMS/panel l=2m
99.8.027	Pro-serie Cable dimming potmeter 5p-DIN l=0.5m
N02.98401	Sub alarm unit bridge timer